GPS*

- **EXIT NAVIGATION AND GPS APPLICATIONS:** After using the Sprint Navigation application, press **Menu** and select **Exit** so your smart device doesn't continue to access location data in the background and use power.

  Other GPS applications such as Google Maps,™ Live Search for Windows Mobile,® and Google Maps may cause power drain even when you are not using the GPS services. Press and hold ok button to bring up **Task Manager** and end these applications. Highlight each application and select **End Task**.

Power Settings

- **DECREASE SCREEN BRIGHTNESS:** Press **Option** and press **Brightness**. Press **Left** < to decrease the brightness, and press ok.
- **SET THE BACKLIGHT TO TURN OFF SOONER:** The display backlight turns off automatically after one minute of inactivity, but you can set it to turn off after 30 seconds. Press **Start** and select **Settings**. Select the **System** tab, and then select **Backlight**. On the **Battery Power** tab, select a shut-off interval from the list.

* Within wireless coverage area only. Email, messaging, and GPS require data services at additional cost. GPS not available in all areas at all times. Wi-Fi within range of Wi-Fi hotspot using 802.11b/g wireless connection. Some Wi-Fi hotspots require fee for usage.

Palm offers FREE setup support:**

1-866-750-PALM (7256)

Learn more about your smart device:

learning.palm.com/sprint

Palm, Inc.
950 W. Maude Avenue
Sunnyvale, CA 94085

palm.com

** Free within first 90 days after purchase. Offer subject to change without notice.

© 2008 Palm, Inc. All rights reserved. Palm and Treo are among the trademarks or registered trademarks owned by or licensed to Palm, Inc. Microsoft and Windows Mobile are trademarks of the Microsoft group of companies. All other brand and product names are or may be trademarks of, and are used to identify products or services of, their respective owners. All screen images are simulated.

P 460 08

palm Treo™ 800w SMART DEVICE

Battery saving

Tips and Tricks

Sprint

In addition to charging your Palm® Treo™ 800w smart device every night, these simple adjustments will help you get the most out of your battery.

Battery

- **TOP OFF YOUR BATTERY:** Your battery will last longer if you top it off frequently instead of charging when it's fully drained. You can charge your Treo 800w from a wall outlet (charger included in box), from a computer (with the included USB sync cable) or in your car with a Vehicle Power Adapter (not included, available from Sprint and online from the Palm Store at store.palm.com).
- **KEEP YOUR BATTERY COOL:** Heat reduces battery performance, so keep your battery out of the sun or a hot car. If your Treo overheats when charging, it may stop charging.
- **CARRY A SPARE:** If you plan to spend a lot of time out and about, like on business trips, it's a good idea to carry an extra battery. Palm's Spare Battery Charger is available at an additional cost and includes a spare Treo 800w battery. You can find it online at the Palm Store at store.palm.com.

Wi-Fi*

- **TURN OFF WI-FI:** Even in areas without Wi-Fi, your smart device will still search for a signal, which uses power. When you don't need it, press and hold the **Wi-Fi** button at the top of the device to turn it off.
- **SET WI-FI TO TURN OFF AUTOMATICALLY:** Set Wi-Fi to stay off until you press the Wi-Fi button. Press **Start** and select **Settings**. Select the Connections tab and then select **Wi-Fi Prefs**. Select **On Button Press**. Wi-Fi will turn off when your device goes to sleep.

Bluetooth

- **TURN OFF BLUETOOTH WIRELESS FEATURE:** Select **Menu** (right softkey), select **Wireless Manager**, and tap the **Bluetooth** button to turn it off when you're not using it.

Phone

- **TURN OFF YOUR PHONE:** If you're in an area with no coverage, or you don't plan to use the phone for awhile—like at night, press and hold **Power/End** to disconnect from your wireless network.

Email*

Manage email synchronization: To save battery life, decrease the frequency of automatic email synchronization —especially during off-peak hours.

- **ADJUST PEAK AND OFF-PEAK TIMES:** Press **Start** and select Programs. Select **ActiveSync**, press **Menu** (right softkey) and select **Schedule**. Then adjust **Off-Peak Times**—like synching 4 hours after work or not synching late at night. You can also adjust **Peak Times**.
- **CUSTOMIZE HIGH-TRAFFIC PERIODS:** Press **Start** and select **Programs**. Select **ActiveSync**, press **Menu** (right softkey) and select **Schedule**. Select the **Peak Times** link at the bottom of the screen and adjust days and times (e.g., if you work Monday–Thursday, select those days as your peak times). Press **ok**.
- **MANUALLY SYNC:** Follow the directions above, then once you get to the **Off-Peak Times** list, select **Manually**. To initiate a manual sync, press **Start**, select **Programs**, and select **ActiveSync**. Press **Sync**.
- **MANAGE PERSONAL EMAIL:** To optimize battery power, select an appropriate synchronization schedule and set other parameters. For example, choose to download only the message headers or to not download attachments.